



- ✓ High security, use with 1 to 8 digit code
- ✓ Warning signal when the battery is low
- ✓ For door thicknesses from 1,0 up to 22,0 mm
- ✓ Emergency opening with masterkey
- ✓ For wooden and metal furniture
- ✓ Single- or multi user version



Technical Drawing



Installation



Article	Description	Closing way	Colour	Item No
NOKY Solo S Set without plate, right	single user for private use, elektronik lever lock with	12-9	black	121 123408
NOKY Solo S Set without plate, left	1-8 digit code, forwooden and metal furniture, incl. lever screws, CE, IP55	6-3	black	121 123422
NOKY Solo S Set without plate, vert. right		3-12	black	121 123415
NOKY Solo P Set without plate, right	multi user for public area, elektronik lever lock with	12-9	black	121 123051
NOKY Solo P Set without plate, left	1-8 digit code, forwooden and metal furniture, incl. lever screws, CE, IP55	6-3	black	121 123401
NOKY Solo P Set without plate, vert. right		3-12	black	121 123394
NOKY Solo Masterkey	for emergency opening	-	blue	113 103157
NOKY Solo backplate	for assembly in doors with thicknesses from 18 - 22 mm, plastic ABS	-	black	121 123058
NOKY Solo backplate	for assembly in doors with thicknesses from 3-7 mm, plastic ABS	-	black	121 124094