# NOKY G

Electronic lock for single-user


- Fixed code from 1 to 8 digits between 1 and 44444444
- Single-user with configuration required
- Emergency opening with a master key
- For door thicknesses up to 29 mm
- Required battery: CR 2032 (3V) not included in the scope of delivery







## Details

**Locking path**
**12 ➙ 9 h**




## Technical drawings




| Article | Description | Locking path | Colour | Item No. |
|---|---|---|---|---|
| **NOKY G electronic locking system** | Single-user, vertical, for wooden furniture, 1x straight lever, 1x strike plate, 4x screws, 1x hexagon nut, 2x washers, plastic ABS, battery not included | 12 - 9 o'clock | Black | 121 104431 |
| **NOKY G master key** | For emergency opening | - | Red | 121 104669 |
| **NOKY G battery holder** | Mounting for battery of electronic lock | - | Black | 121 104676 |